



Owner's Manual Addendum

20200206v1

IMPORTANT: Due to constant improvement in the design and quality of our vehicles, changes to a vehicle configuration can occur which affect the Owner's Manual information after the supply for production has already been printed.

A change to the engine management system made before production requires an update to Page 68, Item 20, of the 2019 UFORCE 1000 Owner's Manual.

The Mode Display information described is not available. 'S' mode is the standard program mode.

Please reference the following corrected page 68 for all 2019 UFORCE1000 UTVs:

Controls and Features

Odo/Trip/Rpm/EngHr/V/Bright - 19

Indicates the total mileage the vehicle has traveled. Press SEL button to toggle to TRIP meter, or tachometer, RPM, or engine hour, or battery voltage, or dashboard brightness.

Mode Display - 20

'S' = Standard Mode. Mode selection is not available.

SEL - 21

Use the SEL button to toggle through the information area options.

Drive Method - 22

It indicates 2WD, 4WD or 4WD-LOCK drive method chosen.

Place a copy of revised Page 68 in your MY2019 UFORCE 1000 Owner's Manual.

CFMOTO apologizes for the error.